

Favolite

Favolite Stage Lighting Co., Ltd

Vader BWS 350 (300W LED, Spot/Beam/Wash)

21CH			
1	pan	0~255	
2		0~255	
3	tilt	0~255	
4	tilt fine	0~255	
5	colour wheel	0~7	no colour
		8~15	colour1
		16~23	colour2
		24~31	colour3
		32~39	colour4
		40~47	colour5
		48~55	colour6
		56~63	colour7
		64~71	colour8
		72~79	colour9
		80~87	colour10
		88~95	colour11
		96~103	no colour
		104~221	colour Arbitrary positioning
		222~238	Rotate left
		239~255	Rotate right
	cyan	0~255	
	magenta	0~255	
	yellow	0~255	
	colour temperature	0~255	
6	fix gobo	0~3	no gobo
		4~7	gobo1
		8~11	gobo2
		12~15	gobo3
		16~19	gobo4
		20~23	gobo5
		24~27	gobo6
		28~31	gobo7
		32~35	gobo8
		36~39	gobo9
		40~43	gobo10
		44~47	gobo11
		48~51	gobo12
		52~55	gobo13
		56~59	no gobo
		60~67	gobo1 shake from slow to fast
		68~75	gobo2 shake from slow to fast
		76~83	gobo3 shake from slow to fast
		84~91	gobo4 shake from slow to fast
		92~99	gobo5 shake from slow to fast
		100~107	gobo6 shake from slow to fast
		108~115	gobo7 shake from slow to fast
		116~123	gobo8 shake from slow to fast
		124~131	gobo9 shake from slow to fast
		132~139	gobo10 shake from slow to fast
		140~147	gobo11 shake from slow to fast
		148~155	gobo12 shake from slow to fast
		156~163	gobo13 shake from slow to fast
		164~167	no gobo
		168~211	Rotate left
		212~255	Rotate right

Favolite

Favolite Stage Lighting Co., Ltd

7	R-gobo	0~7 8~15 16~23 24~31 32~39 40~47 48~55 56~63 64~71 72~79 80~87 88~95 96~103 104~111 112~119 120~127 128~135 136~195 196~255	no gobo gobo1 gobo2 gobo3 gobo4 gobo5 gobo6 gobo7 no gobo gobo1 shake from slow to fast gobo2 shake from slow to fast gobo3 shake from slow to fast gobo4 shake from slow to fast gobo5 shake from slow to fast gobo6 shake from slow to fast gobo7 shake from slow to fast no gobo Rotate left Rotate right
8	gobo rotation	0~3 4~123 124~187 188~191 192~255	no effect R-gobo angle rotate left stop rotate right
9	dimmer	0~255	
10	strobe	0~3 4~67 68~99 100~131 132~175 176~247 248~251 252~255	open strobe 1 strobe 2 strobe 3 strobe 4 strobe 5 random strobe1 random strobe2
11	dimer mode	0~63 64~127 128~191 192~255	Refresh rate 1200 auto Refresh rate 1200 fast Refresh rate 13672 auto Refresh rate 13672 fast
12	prism	0~31 32~255	no prism prism1 on
13	prism rotation	0~3 4~123 124~187 188~191 192~255	prism stop prism angle rotate left fast to slow stop rotate right slow to fast
14	zoom	0~255	
15	focus	0~255	
16	Auto focus distance (Reserved)	0~3 4~63 64~127 65~191 192~255	Do not use auto focus 5m 7.5m 10m 15m
17	Auto focus distance fine (Reserved)	0~255	Continuous adjustment within the above distance range
18	iris open	0~127 128~135 136~173 174~211 212~249 250~255	open to close close iris movement 1 iris movement 2 iris movement 3 close

Web: www.favo-lite.com Tel/Fax: +86 020 2666 8669

Address: Room 401 and 402, Building 23, Haichuang Han's Robot Intelligent Manufacturing Center, Shunde District, Foshan City, Guangdong Province, China

Favolite

Favolite Stage Lighting Co., Ltd

19	frost	0~9 10~255	no effect liner frost
20	scan speed	0~255	fast to slow
21	control	0~19 20~29 30~39 40~49 50~59 60~69 70~74 75~79 80~84 85~89 90~94 95~99	no used reset all reset pan,tilt reset colour,gobo,CMY,CTO reset zoom,focus,prism,frost No effect display default display off(don't Keep after shutdown) display on(don't Keep after shutdown) fan speed low(Keep after shutdown) fan speed medium(Keep after shutdown) fan speed high(Keep after shutdown)
Please hold the value for more than 8 seconds to take effect,and then return to 0 to avoid repeated activation.			